

Zl Haneboesch L-4562 Differdange LUXEMBOURG Phone : +352 58 22 82 1 Fax : +352 58 49 35 E-mail : sales@airtech.lu Website : www.airtech.lu

Data Sheet



DESCRIPTION

The Airtech Resin infusion connector (RIC) provides inexpensive and efficient through bag connection for vacuum manifold and resin feed lines for low temperature resin infusion applications.

TECHNICAL DATA

Material type Maximum use temperature Polyethylene UHMW 80 °C

SIZES

Product reference	Tube connection	Spiral tube connection
RIC 12	1/2 inch	1/2 inch
RIC 58	5/8 inch	5/8 inch
RIC 34	3/4 inch	3/4 inch



NOTES

- > Select RIC to fit tube and spiral employed and position as desired, then complete vacuum bag.
- > Cut polyethylene tube on angle and apply wrap of vacuum sealant tape above cut.
- > Smooth bag film over RIC and pierce film with angled tube until vacuum sealant seals connection.

Last updated : 2012-07-24

Catalogue position : Resin infusion products

As the conditions or methods of use, including storage, are beyond our control, Airtech Europe does not assume any responsibility for the performance of this material for any particular use. The material is sold "as is". Airtech Europe disclaims, and buyer waives, any and all implied warranties, including without limitation the implied warranties of merchantability and of fitness for particular use. The information contained herein represents typical properties and should not be used for specification purposes. This translation is provided for your convenience only. The official language is English and the official law is Luxembourg.